

★スナップリング軸用

4	●	26	●	63	●	145	●
5	●	27	●	65	●	150	●
6	●	28	●	68	●	160	●
7	●	29	●	70	●	165	●
8	●	30	●	72	●	170	●
9	●	32	●	75	●	175	●
10	●	34	●	78	●	180	●
11	●	35	●	80	●	190	●
12	●	36	●	82	●	200	●
13	●	38	●	85	●	210	●
14	●	40	●	88	●	220	●
15	●	42	●	90	●	230	●
16	●	45	●	95	●	240	●
17	●	47	●	100	●	250	●
18	●	48	●	105	●	260	●
19	●	50	●	110	●	270	●
20	●	52	●	115	●	280	●
21	●	55	●	120	●	290	●
22	●	56	●	125	●	300	●
23	●	58	●	130	●		
24	●	60	●	135	●		
25	●	62	●	140	●		

★スナップリング穴用

10	●	36	●	78	●	155	●
11	●	37	●	80	●	160	●
12	●	38	●	82	●	165	●
13	●	40	●	85	●	170	●
14	●	42	●	88	●	175	●
15	●	45	●	90	●	180	●
16	●	46	●	92	●	185	●
17	●	47	●	95	●	190	●
18	●	48	●	98	●	200	●
19	●	50	●	100	●	210	●
20	●	52	●	102	●	220	●
21	●	55	●	105	●	230	●
22	●	56	●	110	●	240	●
24	●	58	●	112	●	250	●
25	●	60	●	115	●	260	●
26	●	62	●	120	●	270	●
28	●	63	●	125	●	280	●
29	●	65	●	130	●	290	●
30	●	68	●	135	●	300	●
32	●	70	●	140	●		
34	●	72	●	145	●		
35	●	75	●	150	●		

★丸S形止め輪

8	●	38	●
9	●	40	●
10	●	42	●
11	●	45	●
12	●	50	●
13	●	52	●
14	●	60	●
15	●	65	●
16	●	70	●
17	●		
18	●		
19	●		
20	●		
21	●		
22	●		
24	●		
25	●		
26	●		
28	●		
30	●		
32	●		
35	●		

★丸R形止め輪

10	●	37	●
11	●	38	●
12	●	40	●
13	●	42	●
14	●	45	●
15	●	47	●
16	●	48	●
17	●	50	●
18	●	52	●
19	●	55	●
20	●	58	●
21	●	60	●
22	●	62	●
24	●	68	●
25	●	72	●
26	●	75	●
28	●		
30	●		
32	●		
34	●		
35	●		
36	●		

★Eリング

	クロマト	三価
3	●	●
4	●	●
5	●	●
6	●	●
7	●	●
8	●	●
9	●	●
10		●
12		●
15	●	●
19	●	●
24	●	

★Eリング ハーカ

1.5	●
2	●
2.3	●
2.5	●
3	●
4	●
5	●
6	●
7	●
8	●
9	●
10	●
12	●
15	●
19	●
24	●

★Eリングホルダー

ETW	1.2	●
ETW	1.5	●
ETW	2.2	●
ETW	2.5	●
ETW	3	●
ETW	4	●
ETW	5	●
ETW	6	●
ETW	7	●
ETW	8	●
ETW	9	●
ETW	10	●
ETW	12	●

★ETスタンド

1.2	●
1.5	●
2	●
2.5	●
3	●
4	●
5	●
6	●
7	●
8	●
10	●
12	●